



## INSTRUCTIONS



1. Fill your vessel with 15-20 litres of fresh water.
2. Slide on the mounting hooks supplied onto the back of the Water Heater



3. Connect Circulation Pump to longer tube supplied.
4. Connect other end of longer tube to 'Water In' inlet on the Water Heater.
5. Connect small tube supplied to 'Water Out' outlet on the Water Heater.



6. Hang Water Heater on the side of the vessel and submerge Circulation Pump only into the water.



7. Plug Circulation Pump power cord into Circulation Pump power supply on the Water Heater.
8. Plug Solar Panel into MC4 connections on the Water Heater.



9. Set desired temperature set point using '+' and '-' selectors on the Water Heater.

