




## 24 Volt Battery Connection To Copperhead Water Heater



### Parts Required

- MC4 Connectors For Copperhead Heater Connection
- 10 Amp Fuse & Holder
- 10 amp Wire